



# WESSEX INTUMESCENT SUPPLIES LTD

Unit 22, Regent Trade Park, Barwell Lane, Gosport, Hants. PO13 0EQ

Fire, Draught, Weather & Acoustic Seals  
Conservatory Roof Glazing Systems

Tel: 01329 221111 Fax: 01329 221122

Email: sales@wis-ltd.com

Website: www.wis-ltd.com

## Security Glazing Tape

### Description

A closed cell compressible pvc foam tape coated on both sides with aggressive adhesives that effectively bonds glass into window frames whilst also acting as an efficient and long lasting glazing seal. Once in place the product makes it very difficult to remove the glass from the outside.

### Benefits

- Easy to install and maintenance free
- Long term weathering, ageing and UV resistance



### Availability

Widths	Thickness		
	10mm	1mm	2mm
12mm	1mm	2mm	3mm
15mm	*	2mm	3mm

*Other widths/thicknesses available to special order in box quantities*

**Coil length:** Varies against width/thickness contact sales department for details

**Colours:** Black or White

### Application / Installation

All surfaces must be clean, dry and free from all contaminants ie. grease, silicones, dust and the air temperature and bonding items (tape, bars & glass) are above 10°C prior to application.

Use Isopropanol or similar cleaner to ensure clean contact surfaces.

Position tape on glazing leg so that the tape edge is aligned flush with the sight line. Initial adhesion is obtained by applying firm, uniform pressure to the tape during application, prior to liner removal. Tape on horizontal rebate should run past the verticals, the tape should be cut by knife cut and butted closely together at corners without overlapping. After application of tape the liner should not be removed until glass is ready for placement; avoid any unnecessary adhesive exposure.

The tape should be used under 30% compression for optimum adhesive performance and to provide an effective weather seal. Setting blocks are recommended for all window and door systems. Position setting blocks on bottom rail as required, immediately prior to glazing remove the protective release paper and carefully position glass. Finally fix external beads into position ensuring tape is compressed.

Windows/Doors should be stored in a position where the weight of the glass is on the tape.